


## C400 3000 VA Series UPS



## Installation/Manual

LC-3206 - 16/04/19



---

# CONTENT

<b>1.SAFETY AND EMC INSTRUCTIONS</b> .....	<b>4</b>
1.1 INSTALLATION .....	4
1.2 OPERATION .....	5
1.3 MAINTENANCE, SERVICING AND FAULTS.....	6
1.4 TRANSPORT .....	6
1.5 STORAGE.....	6
1.6 STANDARDS .....	7
<b>2.DESCRPTION OF COMMONLY USED SYMBOLS</b> .....	<b>8</b>
<b>3.INTRODUCTION</b> .....	<b>8</b>
<b>4.PANEL DESCRIPTION</b> .....	<b>9</b>
4.1 BUTTON .....	10
4.2 LCD DESCRIPTION.....	11
<b>5.CONNECTION AND OPERATION</b> .....	<b>13</b>
5.1 INSPECTION: .....	13
5.2 CONNECTION: .....	13
5.3 BATTERY RECHARGE:.....	15
5.4 TURN ON THE UPS: .....	15
5.5 TEST FUNCTION:.....	15
5.6 TURN OFF THE UPS:.....	16
5.7 AUDIBLE ALARM MUTE FUNCTION: .....	16
<b>6.OPERATING MODE</b> .....	<b>17</b>
6.1 LINE MODE .....	18
6.2 BATTERY MODE .....	19
6.3 BYPASS MODE .....	19
6.4 NO OUTPUT MODE.....	19
6.5 EPO (EMERGENCY POWER OFF) .....	20
6.6 ECO MODE (ECONOMY MODE) .....	20
6.7 CVCF MODE .....	21
6.8 ABNORMAL MODE .....	21
<b>7.SETTING BY LCD MODULE</b> .....	<b>22</b>
<b>8.TROUBLE SHOOTING</b> .....	<b>26</b>
<b>9.MAINTENANCE</b> .....	<b>29</b>
9.1 OPERATION .....	29
9.2 STORAGE.....	29
<b>10.TECHNICAL DATA</b> .....	<b>29</b>

10.1 ELECTRICAL SPECIFICATIONS .....29  
10.2 OPERATING ENVIRONMENT .....30  
10.3 TYPICAL BACKUP TIME (TYPICAL VALUES AT 25°C IN MINUTES ).....30  
10.4 DIMENSIONS AND WEIGHTS .....30

**11.COMMUNICATION PORT .....31**

11.1 USB AND RS-232(OPTIONAL) COMMUNICATION PORTS .....31  
11.2 USB FOR HID POWER DEVICE .....31  
11.2 AS400 INTERFACE (OPTIONAL) .....31  
11.1 CMC INTERFACE (OPTIONAL).....31  
11.2 NMC INTERFACE (OPTIONAL).....31


# 1. Safety and EMC Instructions

**Please read carefully the following user manual and the safety instructions before installing or operating the unit.**

## 1.1 Installation

- See installation instructions before connecting to mains power.
- Condensation should occur if the UPS is moving directly from a cold to a warm environment. The UPS must be absolutely dry before being installed. Please allow an acclimatisation time of at least two hours.
- Do not install the UPS near water or in damp environment.
- Do not install the UPS where it would be exposed to direct sunlight or near other heat sources.
- Do not connect appliances or items of equipment which would overload the UPS (e.g. laser printers, etc.) to the UPS output.
- Place cables in such a way that no one can step on or trip over them.
- Use a reliable earth source.
- Only connect the UPS to an earthed shockproof outlet socket.
- The building outlet connection must be easily accessible to disconnect from the UPS.
- When installing the UPS check that the sum of the leakage current of the UPS and the connected load does not exceed 3.5mA.

Do not block the ventilation openings on the UPS housing. Ensure the air vents on the front, side and rear of the UPS are clear at all times. At least 25cm of space on each side is recommended. The air flow diagram is shown as below:



■ Figure 1.1 Air flow diagram

- This UPS is powered by more than one source, disconnection of the AC source and the DC source is required before servicing.
- An additional circuit breaker or fuse with rating 16A and breaking capacity 3kA shall be used between power source and input when installation this unit.

## 1.2 Operation

- Do not disconnect the mains cable on the UPS or the building wiring socket (grounded shockproof socket) during operation as this would remove the ground to the UPS and of all connected loads.
- The UPS features its own internal current source (batteries). There is risk of electrical shock from the UPS output sockets or output terminal block even if the UPS is not connected to mains supply.
- In order to fully disconnect the UPS, first press the ON/OFF button to turn off the UPS, then disconnect the mains lead.
- Ensure that no liquid or other external objects can enter the UPS.
- Do not remove the enclosure. This system is to be serviced by qualified service personnel only.
- Remove the protective panel only after disconnecting the terminal connections.

### **1.3 Maintenance, servicing and faults**

- The UPS operates with hazardous voltages. Repairs may be carried out only by qualified maintenance personnel.
- Caution - risk of electric shock. Even after the unit is disconnected from the mains power supply (building wiring socket), components inside the UPS are still connected to the battery which are potentially dangerous.
- Before carrying out any kind of service and/or maintenance, disconnect the batteries. Verify that no current is present and no hazardous voltage exists in the capacitor or BUS capacitor terminals.
- Batteries must be replaced only by qualified personnel.
- Caution - risk of electric shock. The battery circuit is not isolated from the input voltage. Hazardous voltages may occur between the battery terminals and the ground. Verify that no voltage is present before servicing.
- Batteries have a high short-circuit current and pose a risk of shock. Take all precautionary measures specified below and any other measures necessary when working with batteries: remove all jewelry, wristwatches, rings and other metal objects, only use only tools with insulated grips and handles.
- When changing batteries always replace with the same quantity and the same type of batteries.
- Do not attempt to dispose of batteries by burning them. It could cause an explosion.
- Do not open or modify batteries. Effluent electrolyte can cause injury to the skin and eyes and is considered toxic.
- Please replace the fuse only by a fuse of the same type and of the same amperage in order to avoid fire hazards.
- Do not dismantle the UPS, except for qualified maintenance personnel.

### **1.4 Transport**

- Please transport the UPS only in the original packaging (to protect against shock and impact).

### **1.5 Storage**











- The UPS must be stockpiled in the room where it is ventilated and dry.

## 1.6 Standards

<b>* Safety</b>	
IEC/EN 62040-1	
<b>* EMI</b>	
Conducted emission.....:IEC/EN 62040-2	Category C2
Radiated emission.....:IEC/EN 62040-2	Category C2
Harmonic current.....:IEC/EN 61000-3-2	
Voltage fluctuation and flicker.....:IEC/EN 61000-3-3	
<b>*EMS</b>	
ESD.....:IEC/EN 61000-4-2	Level 3
RS.....:IEC/EN 61000-4-3	Level 3
EFT.....:IEC/EN 61000-4-4	Level 4
SURGE.....:IEC/EN 61000-4-5	Level 4
CS.....:IEC/EN 61000-4-6	Level 3
MS.....: IEC/EN 61000-4-8	Level 4
Voltage Dips.....: IEC/EN 61000-4-11	
Low Frequency Signals.....:IEC/EN 61000-2-2	

## 2. Description of commonly used symbols

Some or all of the following symbols may be used in this manual. It is advisable to familiarise yourself with them and understand their meaning:

Symbol and Explanation			
Symbol	Explanation	Symbol	Explanation
	Alert you to pay special attention		Alternating current source (AC)
	Caution of high voltage		Direct current source (DC)
	Turn on the UPS		Protective ground
	Turn off the UPS		Recycle
	Idle or shut down the UPS		Do not dispose with ordinary trash

## 3. Introduction

This Online-Series is an uninterruptible power supply incorporating double-converter technology. It provides perfect protection specifically for sensitive IT equipment.

The double-converter principle eliminates all mains power disturbances. A rectifier converts the alternating current from the socket outlet to direct current. This direct current charges the batteries and powers the inverter. On the basis of this DC voltage, the inverter generates a sinusoidal AC voltage, which permanently supplies the loads.


Computers and periphery are thus powered entirely by the mains voltage. In the event of power failure, the maintenance-free batteries power the inverter.

This manual covers the UPS listed as follows. Please confirm whether it is the model you intended to purchase by performing a visual inspection of the Model No. on the rear panel of the UPS.




Item	Model name	Power Rating	Model type	Model description	Other
1	C400-030-B	3000VA/ 2700W	Tower	Standard model	Single Phase input Single Phase Output

### UPS Block Diagram



### 4. Panel Description

The display panel of C400-010 / 020 / 030-B (C) are all the same as shown as below:




■ Figure 4.1 Display panel

## 4.1 Button

Switch	Function
<b>ON/Silence Button</b>	Turn on UPS system: By pressing the ON-Button continuously for more than 1 second the UPS system is turned on. Deactivate acoustic alarm: By pressing this Button an acoustic alarm can be deactivated in the battery mode. By short touch this Button all acoustic alarms can be deactivated in all modes. Perform battery test: By pressing this Button the UPS can do a battery test within Line mode, ECO mode or CVCF mode.
<b>OFF Button</b>	When mains power is normal, the UPS system switches to No output or Bypass mode by pressing OFF-Button “⏻”, and the inverter is off. At this moment, if Bypass is enabled, then the output sockets are supplied with voltage via the bypass if the mains power is available. Deactivate acoustic alarm: By pressing this Button an acoustic alarm can be deactivated in the bypass mode. Release the UPS from fault mode and EPO status.
<b>Select Button</b>	The output voltage, frequency, Bypass disable/enable and operating mode in No output or Bypass mode, Battery Ah, Battery remain time
<b>Enter Button</b>	display disable/enable and Charger current in all modes, could be selected by pressing Select-Button, and confirmed by pressing Enter-Button.






## 4.2 LCD description



■ Figure 4.2 LCD display

### LCD icon function

Display	Function
Input Information	
	Indicates input voltage/frequency value, which are displayed alternately.
	Indicates the input is connected with mains, and the input power is single phase input.
Output Information	
	Indicates output voltage/frequency value, which are displayed alternately.

Load Information	
	<p>Indicates the load level. Every grid represents the level of 20%. One grid would be displayed if the level is 0~20%</p>
Battery Information	
	<p>Indicates the battery capacity. Every grid represents the capacity of 20%.</p>
Mode/Fault/Warning Information	
	<p>Indicates the operating mode Fault type, Warning type or battery remaining time, several warning types at the same time could be displayed alternately.</p>
Misc	
	<p>Indicates the UPS is in setting mode.</p>
	<p>Indicates the UPS is in Fault mode or has some warnings.</p>

## 5. Connection and Operation

The system may be installed and wired only by qualified electricians in accordance with applicable safety regulations!

When installing the electrical wiring, please note the nominal amperage of your incoming feeder.

### 5.1 Inspection:

Inspect the packaging carton and its contents for damage. Please inform the transport agency immediately if you find signs of damage.

Please keep the packaging in a safe place for future use.

**Note: To avoid any safety issue, please ensure that the incoming feeder (mains) is isolated completely while whole installing process.**

### 5.2 Connection

#### (1) UPS Input Connection

If the UPS is connected via the power cord, please use the correct socket with protection against electric current, and pay attention to the capacity of the socket. The UPS System has an input breaker on the standard cabinet.

#### (2) UPS Output Connection

The output sockets are shown below:


Model No.	Output Socket -IEC(pcs)
C400-030-B	4*C13+1*C19

#### (4) EPO Connection


EPO (Emergency Power Off) function is a standard feature for these UPS, the polarity of EPO is configurable; EPO is normally close as default setting. If the connection between two ports of the EPO connector is disconnected, EPO function will be active and the UPS will stop output power immediately.

- Normally open

Normally the EPO connector is open on the rear panel. Once the connector is closed with a wire, the UPS will stop output until EPO status is reset.




Disable EPO status




Enable EPO status

- Normally closed

Normally EPO connector is closed with a wire on the rear panel. Once the connector is open, the UPS will stop output until the EPO status is disabled.



Enable EPO status



Disable EPO status

### 5.3 Battery recharge

Fully charge the batteries (external) of the UPS system by leaving the UPS system connected to the mains power for 1-2 hours approximately. The UPS system is able to operate immediately without undertaking the recharging process, but the backup time may be shorter than the nominal value specified.

### 5.4 Turn on the UPS

#### (1) With mains power connecting:

Press On-button continuously for more than 1 second to turn on the UPS, the UPS will move onto the Line mode; the LCD screen will indicate the status of the UPS.

#### (2) Without mains power connecting:

Even though mains power is not connected to the UPS, the UPS still can be turned on by just simply pressing on button continuously for more than 1 second with external batteries connected, the UPS will get into the Battery mode, and the LCD screen will indicate the state of the UPS.

***Note: The default setting for bypass mode is no output after UPS is connected to mains power and the breaker is turned on. This can be configurable.***

### 5.5 Test function

Test function is checking battery performance of the UPS system by pressing the On-Switch for more than 1 second while the UPS is operating in Line mode. The UPS will detect whether the battery is connected or the battery has reduced capacity. The UPS can also implement this test automatically and periodically, the time period is configurable.

## 5.6 Turn off the UPS

### **(1) In Line Mode:**

Press OFF button continuously for more than 1 second to turn off the UPS, the UPS will go into no output or bypass mode. In this situation, the UPS might have output power if bypass mode is enabled. Disconnect the mains power to turn off the output.

### **(2) In Battery Mode:**

Press OFF button continuously for more than 1 second to turn off the UPS, the UPS will get into no output or standby mode. After 10s UPS will be shutdown completely.

## 5.7 Audible alarm mute function

If the audio alarm is not required in battery mode, the audio alarm is able to be muted by pressing the ON button continuously for more than 1 second. Moreover, the audible alarm will be active again when the battery reaches low status to remind the end user that UPS output power will shutdown soon.

If the audible alarm is not required in bypass mode, the audible alarm is able to be muted by pressing the OFF button continuously for more than 1 second. This action doesn't affect the warning and fault alarm.

In any mode, if the warning or fault alarm is not required, you can mute it by pressing the ON button for less than 0.5 second, and enable it by pressing the ON button for less than 0.5 second again. If a new warning or fault alarm appears, the buzzer will beep again.



## Alarm Table List

NO.	Status	Alarm
1	Battery mode	Beep once every 4 sec
2	Battery mode with battery low	Beep once every sec
3	Bypass mode	Beep once every 2 min
4	Overload	Beep twice every sec
5	Warning active (see Warning & Fault Code Table )	Beep once every sec
6	Fault active	Beep continuously
7	Button function active	Beep once

## 6. Operating Mode

Different messages/strings will be displayed on the LCD screen corresponding to different UPS operating modes, as shown in the following table 6.1. Different Warning/fault code, as shown in the following table 6.2. Only one normal operating string or fault string is presented a time. However if several warnings happen at the same time, they will be displayed on the LCD alternately. In this case, the normal operating mode string and the warning string will be shown circularly. Once a fault comes forth, all previous warnings will not be shown again; only the fault string will be presented.

Table 6.1: Operating Mode


Operating mode	Code
No output mode	STbY
Bypass mode	bYPA
Line mode	LINE
Battery mode	bATT
Battery test mode	TEST
ECO mode	ECO
Converter mode	CVCF

Table 6.2 : Warning & Fault Code

Warning	String
Site fail	SITE
Fan fail	FANF
Battery over voltage (over charged)	HIGH
Battery low	bLOW
Charge fail	CHGF
Inverter temperature high	TEPH
Battery open	bOPN
Overload	OVLD
Digital bigger charger fail	dCHF
Inner temperature high	ITPH
Fault	String
Inverter short	SHOR
Overload fault	OVLD
Inverter soft start fail	ISFT
Bus soft start fail	bSFT
Over temperature fault	OVTP
Inverter Volt Low	INVL
Inverter Volt High	INVH
Bus volt over	bUSH
Bus volt Low	bUSL
Bus short	bUSS
Inverter NTC open	NTCO
Emergency Power Off	EPO

### 6.1 Line mode

The LCD display in Line mode is shown as figure 6.1. The information about the mains power, the battery level, the UPS output and the load level will be displayed. The “LINE” string indicates UPS working in Line mode.




■ Figure 6.1 Line mode

## 6.2 Battery mode

The LCD display in battery mode is shown as figure 6.2. The information about the battery voltage, the battery level, the UPS output and the load level will be displayed. The “bATT” string indicates UPS working in battery mode. If the function of battery remain time is set to enable, the “bATT” string and battery remaining time (in unit Min or Sec) would display in turn every 2s.


When the UPS is running in battery mode, the buzzer beeps once every 4 seconds. If the “ON” button on the front panel is pressed for more than 1 second, the buzzer will stop beeping (in silence mode). Press the “ON” button once again for more than 1 second to resume the alarm function.



■ Figure 6.2 Battery mode

## 6.3 Bypass mode


The LCD display in bypass mode is shown as figure 6.3. The information about the mains power, the battery level, the UPS output and the load level will be displayed. The UPS will beep once every 2 minutes in bypass mode. The “bYPA” string indicates UPS working in the bypass mode.



■ Figure 6.3 Bypass mode

## 6.4 No Output mode

The LCD display in no output mode is shown as figure 6.4. The information about the mains power, the battery level, the UPS output and the load level could be displayed. The “STbY” string indicates UPS working in the No output mode.




■ Figure 6.4 No output mode

## 6.5 EPO (Emergency Power Off)

It is also called RPO (Remote Power Off). On LCD display, the word of “EPO” will be presented in the position of output voltage.

It is a special status which the UPS will shut the output off and send out an alarm. The UPS cannot be turned off by pressing “OFF” button on the panel, only after resetting EPO status.



■ Figure 6.5 Fault mode

## 6.6 ECO mode (Economy mode)

It is also called high efficiency mode. After turning the UPS on in ECO mode, the output power will be supplied from mains power directly via an internal filter while the mains power is in certain range, so the high efficiency performance would be gained in ECO mode. Once the mains power is lost or out of range, the UPS will transfer to battery mode and the load will be supplied continuously by the battery.

- 1) ECO mode can be enabled through the LCD setting or the software (Winpower, etc.).
- 2) The transfer time of UPS output from ECO mode to battery mode is less than 10ms. It is suggested that this may not be suitable for applications involving sensitive loads.

## 6.7 CVCF mode

CVCF (Constant Voltage Constant Frequency) which is also called converter mode, UPS will work in frequency free-run with a fixed output frequency (50Hz or 60Hz). Once the mains are lost or abnormal, the UPS will transfer to battery mode and the load is supplied continuously by the battery.

- 1) CVCF mode can be enabled through the LCD setting or the software (Winpower, etc.).
- 2) The normal power rating will be derated to 60% in converter mode.


## 6.8 Abnormal mode

In abnormal mode such as Bus fault etc., the corresponding fault string would be shown on the LCD display to indicate the status of the UPS, and the background light will become red in colour. For example "SHOR" would be shown when the connected load or the UPS output is in short-circuit, the LCD display is shown as figure 6.5 followings.

## 7. Setting by LCD Module

The output voltage/frequency, Auto bypass status, operating mode in No output mode or Bypass mode, charger current, external Battery AH and battery remaining time function in all models can be set directly through LCD module.

In bypass or no output mode, pressing the “Enter” button on the LCD panel for more than 1 second will enter the setting mode. The LCD display is shown in the following figure 7.1. The string “OPV” that stands for output voltage. “230Vac” indicates the existing output voltage is 230Vac. If you want to set output voltage, press the “Enter” button for more than 1 second, a flickering string “220” would be shown, if the “Enter” button is pressed again, the string “220” stop flickering, the output volt is changed to 220V; if the “Select” button is pressed for more than 1 second, the next flickering string “230” appear, the order of flickering string is 220 – 230 – 240 – 220 – 230, Press “Enter” button to confirm the output voltage what you want.




■ Figure 7.1 Setting by LCD

To exit the settings mode, press once on the “Enter” button; to continue setting, press the “Select” button. If you do not press on the “Select” or “Enter” button within 10 seconds, the setting mode will exit automatically.


The output frequency string “OPF”, Bypass status string “bYPA”, operating mode string “MOdE”, External Battery Ah string “EbAH”, battery remaining time string “bATT”, Charger current string “CHG” would be presented circularly. The only one voltage value can be selected in “220V”, “230V”, “240V” at any time; Only one

frequency value can be selected in “50Hz”, “60Hz” at any time; Bypass status can be selected in “000” or “001”(Here 000 means Bypass Disable, 001 means Bypass Enable), The UPS would turn to bypass mode within a few seconds if “Bypass Enable” is selected, and turn to no output mode within a few seconds if “Bypass Disable” is selected; Operating mode can be selected in “UPS”, “ECO”, “CVF”(Here “UPS” means the normal online mode, “ECO” means the high efficiency mode, and “CVF” means the converter mode), The mode change would be active only after the UPS is turned on; External Battery Ah could be selected from “005” to “300”(Here “005” means 5Ah total external battery); The battery remaining time function could be selected in “000” or “001”. (Here 000 means battery remaining time function is disabled, then the battery remaining time will not display on the LCD in battery mode. 001 means battery remaining time function is enabled, then in battery mode or battery test mode the battery remaining time will display (in unit Min or Sec) and string “bATT” would display on LCD in turn every 2s.


- An example for changing the Operating mode from normal mode to converter mode through the LCD display.




**Step 1:** “OPV” after pressing the “Enter” button.



**Step 2:** "OFF" after pressing the "Select" button.




**Step 3:** "bYPA" after pressing the "Select" button.




**Step 4:** "MoDE" after pressing the "Select" button "UPS" is flickering after pressing the "Enter" button.





**Step 5:** “ECO” flickering after pressing the “Select” button.



**Step 6:** “CVF” flickering after pressing the “Select” button. Press the “Enter” button, Short touch “Enter” button exit setting mode.

## 8. Trouble Shooting

If the UPS system does not operate correctly, check the operating status on the LCD display. The Warning code or fault code is shown in Warning & Fault Code Table 6.1

If the UPS system does not operate correctly, please attempt to solve the problem using the table below.

[Table 6.1] :Warning & Fault Codes.

<b>Warning &amp; Fault Code</b>	<b>Problem</b>	<b>Possible cause</b>	<b>Remedy</b>
/	No indication, no warning tone even though system is connected to mains power supply	1) No input voltage 2) Breaker open	1) Check building wiring socket outlet and input cable. 2) Check the Breaker
/	No Communication data	1) RS232 wire is not matched 2) USB wire is not matched	1) check or change the RS232 wire 2) check or change the USB wire
/	Emergency supply period shorter than nominal value	1) Batteries not fully charged 2) Batteries defect	1) Charge the batteries until the Batteries are fully charged 2) Change the batteries or consult your dealer.
FANF	Fan fail	Fan abnormal	Check if the fan is running

HIGH	Battery over voltage	Battery is over charged	Switching to battery mode automatically, and after the battery voltage is normal and the mains is normal, the UPS would Switch to line mode automatically again.
bLOW	Battery low	Battery voltage is low	When audible alarm sounding every second, battery is almost empty.
bOPN	Battery open	Battery pack is not connected correctly	Do the battery test to confirm. Check the battery bank is connected to the UPS. Check the battery breaker is turn on.
CHGF	Charge fail	The charge is broken	Notify dealer.
dCHF	Digital bigger charger fail	The charge is broken	Notify dealer.
bUSH	Bus high	UPS internal fault	Notify dealer
bUSL	Bus low	UPS internal fault	Notify dealer
bSFT	Bus soft start fail	UPS internal fault	Notify dealer
bUSS	Bus short	UPS internal fault	Notify dealer
TEPH	Inverter temperature high	Inside temperature of the UPS is too high	Check the ventilation of the UPS, check the ambient temperature.
ITPH	Inner Ambient temperature high	The ambient temperature is too high	Check the environment ventilation.
INVH	Inverter high	UPS internal fault	Notify dealer
INVL	Inverter low	UPS internal fault	Notify dealer
ISFT	Inverter soft start fail	UPS internal fault	Notify dealer
NTCO	Inverter NTC open	UPS internal fault	Notify dealer

SHOR	Inverter short	Output short circuit	Remove all the loads. Turn off the UPS. Check whether the output of UPS and loads is short circuit. Make sure the short circuit is removed, and the UPS has no internal faults before turning on again.
OVTP	Over temperature fault	Over temperature	Check the ventilation of the UPS, check the ambient temperature and ventilation.
OVLD	Overload	Overload	Check the loads and remove some non-critical loads. Check whether some loads are failed.
SITE	Site fail	Phase and neutral conductor at input of UPS system are reversed	Rotate mains power socket by 180° or connect UPS system.
EPO	EPO active	EPO function is enabled	Plug into the EPO switch.

Please have the following information at hand before contacting the After-Sales Service Department:

1. Model number, serial number
2. Date on which the problem occurred
3. LCD display status, Buzzer alarm status
4. Utility power condition, load type and capacity, environment temperature, ventilation condition
5. The information (battery capacity, quantity) of external battery pack
6. Other information for complete description of the problem

## 9. Maintenance

### 9.1 Operation

The UPS system contains no user-serviceable parts.

### 9.2 Storage

If the batteries are stored in temperate climatic zones, it is recommended to recharge those batteries every three months for 1~2 hours. It is highly suggested to shorten the recharging intervals in every two months at locations where subjects to high temperatures.

## 10. Technical Data

### 10.1 Electrical specifications

INPUT	
Model No.	C400-030-B
Phase	Single
Frequency	40~70 Hz
Current(A)	220/230/240V AC
	14.5/13.9/13.3 A

OUTPUT	
Model No.	C400-030-B
Power rating*	3000VA/2700W
Voltage	220Vac/230Vac/240Vac
Frequency	50/60Hz
Wave form	Sinusoidal

**\*Note: the active power is defined in rated voltage input**

#### BATTERIES

Model No.	C400-030-B
Voltage	72V
Capacity	9Ah

**\*Note: the Capacity of external batteries can be set to 300Ah maximum but it may need more time to fully charge the batteries.**

## 10.2 Operating Environment

Ambient Temperature	0 °C to 40 °C
Operating humidity	< 95%
Altitude	< 1000m <sup>(Note 1)</sup>
	1000m < Altitude ≤ 3000m <sup>(Note 2)</sup>
Storage temperature	-25 °C ~ 55 °C

Note 1: the load no derating

Note 2: the load should derating 1 % for every up 100m


## 10.3 Typical backup time (Typical values at 25°C in minutes)

Model No.	100 % Load	50 % Load
C400-030-B	5'00"	8'30"

## 10.4 Dimensions and weights

Model No.	Dimensions W×H×D (mm)	Net Weight (kg)
C400-030-B	190*327*399	22.7kg

## Appendix - REAR PANEL (IEC)



## **11. Communication Port**

On the rear panel of the UPS (see Appendix), USB & RS232 connectors are standard, as is a Slot for optional connectivity cards.

### **11.1 USB and RS-232 Communication Ports**

To establish communication between the UPS and a computer by use an appropriate communication cable.

### **11.2 USB for HID power device**

The USB interface offers feature “smart battery” which supports HID (Human Interface Device) Power Device Class, no more software installation is needed. Computer’s OS (Operating System) such as Windows/Linux/Mac OS comes with an embedded power management and monitoring function. When a computer connects to UPS via USB cable, the UPS will be automatically recognised by the OS as a “HID UPS Battery”, and user can configure the alarm action in the event of low battery, such as shutting down the computer automatically. UPS with this feature is also ideal as a back-up power for NAS (Network-Attached Storage).

### **11.2 AS400 Interface (Optional)**

It includes isolated dry contact relay outputs for UPS status: such as Mains/Utility failure, Battery low, UPS alarm/OK, or on Bypass and so on. To see more detail about the interface definitions please check the AS400 user manual.

### **11.1 CMC Interface (Optional)**

It provides connection to Modbus protocol with standard RS485 signal. To see more detail please check the CMC user manual.

### **11.2 NMC Interface (Optional)**

NMC (Network Management Card) allows the UPS to communicate in a variety of networking environments and with different types of devices. NMC achieves a remote management for the UPS through internet/intranet. Please contact your local dealer for further information. To see more detail please check the NMC user manual.