

## How to Program Handsets into the Receiver

### If using Channel 1:


1. Press the 'Learn' button once. The red 'Learn' L.E.D. and red 'Channel 1' L.E.D. will light.
2. Press the transmitter button of the handset to be learnt once. The red 'Channel 1' L.E.D. will flash 3 times to confirm that the code learning process was successful.
3. Press the transmitter button of any extra handsets with confirmation as above, or press the 'Learn' button twice to exit programming mode.

### If using Channel 2:


1. Press the 'Learn' button twice. The red 'Learn' LED and green 'Channel 2' L.E.D. will light.
2. Press the transmitter button of the handset to be learnt once. The green 'Channel 2' L.E.D. will flash 3 times to confirm that the code learning process was successful.
3. Press the transmitter button of any extra handsets with confirmation as above, or press the learn button once to exit programming mode.

**Note:-** If the extra handset D.I.P. codes are the same as previously learnt then no further programming is required - WIPA & WBPA versions ONLY.


### Programming Sequence:



**Circuit Board Layout: RR.2WIPA/RR.2WIVA**



**Circuit Board Layout: RR.2WBPA/RR.2WBVA**



### How to Erase the Memory

1. Remove power.
2. Re-apply the power at the same time as depressing the learn button.
3. Maintain the learn button for 10 seconds. The memory is erased and the 'Learn' L.E.D. will light.

**Note:-** To optimise reception, install the antenna far away from obstacles & metal structures and avoid positioning several receivers next to each other. If no antenna is used, reception will be considerably reduced.

### Technical Features

Frequency	433.92 MHz
Antenna	Tuned
Power Supply	24VAC/DC
No. of Tx Codes (Fixed/Rolling)	16/30
Range	30-100m
Channels	2
Relay Contact	1A, 24VDC